# **CLAS12ROOT Overview**

Derek Glazier University of Glasgow

09/09/21




# Recent updates (up to 1.7.6)

chain.db()->turnOffCCDB();

```
Support for vertdoca banks
auto vdentry=c12->vertdoca()->getCombinationEntry(protons[0]->getIndex(),pims[0]->getIndex());
c12->vertdoca()->getIndex1(vdentry); //index in REC::Particle for particle 1
c12->vertdoca()->getIndex2(vdentry); //index in REC::Particle for particle 2
c12->vertdoca()->isTrack1(protons[0]->getIndex(),vdentry);// is the proton particle 1 ?
c12->vertdoca()->getX(vdentry); //Get doca X for protons[0] and pims[0]
c12->vertdoca()->getY(vdentry); //Get doca Y for protons[0] and pims[0]
  Support for trajectories in treemaker
treemaker.CreateBankLink("TRAJFTOFFTOF1A","p->traj(FTOF,FTOF1A)->"):
treemaker.Branch("TRAJFTOFFTOF1A.X/F");
treemaker.Branch("TRAJFTOFFTOF1A.Y/F");
treemaker.Branch("TRAJFTOFFTOF1A.Z/F");
Update clasQADB to v1.2.0
Fix some issues with clas12root::qadb and simulated data
Note HipoSelector can not give correct accumulated charge
Allow to turn off databases
      chain.db()->turnOffQADB();
      chain.db()->turnOffRCDB();
```

# CLAS12ROOT @JeffersonLab Github





# **CLAS12R00T** @JeffersonLab Forum



### https://clas12.discourse.group/c/clas12root



Clas12Root ▶ all tags ▶ Latest Top			+ New Topic 1		
Торіс			Replies	Views	Activity
Reading Bank information in clas12root		<b>D</b> 😩	3	20	2d
Same information in CND1 and FTOF1A		R 🛟 😭	4	15	2d
Using FTbased Pid	last visit		0	13	Aug 30
Restructuring Clas12Tool and Hipo		<b>(2)</b>	6	33	Aug 15
Compile a project with g++ and Clas12Tool as a library		G	1	27	Aug 13
Clas12tool on OSX		<b>⊕ B</b>	2	29	Aug 1
Cherenkov # photoelectrons		• •	1	17	Jul 26
★ About the Clas12Root category		•	0	13	Jul 26




# CLAS12ROOT @JeffersonLab Instructions

### Clas12Root Data Analysis Tools for hipo4 data format Examples are given for running in interactive ROOT sessions and ROOT-Jupyter notebooks Clas12Banks -> Clas12Root NEW We now use an external hipo4 repository. This must be pointed at with the variable HIPO when installing. The files The Class 2 Banks implementation can be used independent of BOOT, although currently BOOT dictionaries are created for Also see c++ function for accessing banks "Cheat sheet" AccesssingBankDataInCpp.txt in the top level directory. To Download To setup Run ROOT seteny CLAS12ROOT \$PWD (the actual path can be added in your bashro or tohro) seteny PATH "\$PATH": "\$CLAS12ROOT/bin" ues with cmake and your ROOTSYS you can try using the local FindROOT file. Edit the CMakeList.txt file removing the lines with comment ##USEROOTSYS and uncomment the line "Note just to belo confuse you the first letter in bank items have been capitilised so where you might expect to use header files e.g. Clas12Banks4/particle.h and look at the get function declarations e.g. getPz() rather than getpz() \*\*

To start an interactive session with pre-loaded Clas12Root use clas12root instead of root on the command line

interactive root session







### Clas12root Download

See README at https://github.com/JeffersonLab/clas12root

```
git clone -recurse-submodules https://github.com/jeffersonlab/clas12root.git
cd clas12root
git checkout v1.7
seteny CLAS12ROOT $PWD
setenv PATH "$PATH": "$CLAS12ROOT/bin"
                                                   i.e local ccdb
#To use the RCDB interface
                                                   cloned as submodule
setenv RCDB HOME /Where/Is/rcdb (e.g. setenv RCDB HOME
                                       ${CLAS12ROOT}/rcdb )
#To use the CCDB interface
setenv CCDB HOME /Where/Is/ccdb
                                                 cd $CCDB HOME
#To use clasqaDB interface
                                                 source environment.csh
                                                 scons
setenv QADB /Where/Is/clasqaDB
                                                 Cd $CLAS12R00T
./installC12Root
```

Note, if the DBs are not set it will compile without

### CLAS12ROOT on ifarm

source /group/clas12/packages/setup.csh
(or setup.sh for bash)

module load clas12/pro or dev

OR module switch clas12root/1.7.6 etc



### CLAS12ROOT Goals

Provide access to hipo file DST data ...and run databases

Links detector data to particles

Runs like ROOT script

Add other ROOT like tools

particleDraw, HipoSelector,...



### **Bank List**

- Event
  - RUN::config
  - REC::Event
- Physics
  - REC::Particle
  - REC:: Response
    - REC::Calorimeter
    - REC::Scintillator
    - REC:: Cherenkov
    - REC::Track
    - REC::Forward Tagger
  - REC::Traj
  - REC::CovMat
- Special
  - HEL::online
  - HEL::flip (tag=1)
  - RUN::scaler (tag=1)
  - RAW: : scaler (tag=1)
  - RAW::epics (tag=1)

Data packed into different banks

Each bank can have a number of entries e.g. REC::Particle::px, REC::Particle::Pid each with the same number of values per event

Different bank can have a different number of values per event

"No" redundant information saved

→ Minimise file size

e.g. if there are 6 particles but only 2 scintillator hits, REC::Scintillator Will contain only 2 values per entry

Note tag=1 banks only written at helcity flip. Many fewer tag=1 events

https://clasweb.jlab.org/wiki/index.php/CLAS12\_DSTs

### **Bank List**

```
Event
```

• RUN::config

• REC::Event

Physics

• REC::Particle

• REC:: Response

REC::Calorimeter

• REC::Scintillator

• REC:: Cherenkov

• REC::Track

REC::Forward Tagger

• REC::Traj

• REC::CovMat

Special

• HEL::online

• HEL::flip (tag=1)

• RUN::scaler (tag=1)

RAW::scaler(tag=1)

RAW::epics (tag=1)

```
"name": "RUN::config",
"group": 10000,
"item" : 11,
"info": "Run Configuration",
"entries": [
   {"name":"run",
                             "type":"I", "info":"RUN number from CODA or
                             "type":"I", "info":"Event number"},
   {"name":"event",
    {"name":"unixtime",
                             "type":"I", "info":"Unix time (seconds)"},
                             "type": "L", "info": "trigger bits"},
    {"name":"trigger",
    {"name":"timestamp",
                             "type":"L", "info":"time stamp from Trigger
                             "type": "B", "info": "type of the run"},
    {"name":"type",
    {"name":"mode",
                             "type": "B", "info": "run mode"},
    {"name":"torus",
                             "type": "F", "info": "torus setting relative
    {"name": "solenoid",
                             "type": "F", "info": "solenoid field setting
```



### **Bank List**

```
Event
```

• RUN::config

• REC::Event

#### Physics

• REC::Particle

• REC::Response

• REC::Calorimeter

• REC::Scintillator

• REC:: Cherenkov

• REC::Track

REC::Forward Tagger

• REC::Traj

• REC::CovMat

#### Special

• HEL::online

• HEL::flip (tag=1)

RUN::scaler (tag=1)

RAW::scaler(tag=1)

RAW::epics (tag=1)

```
"name": "REC::Event",
"group": 300,
"item" : 30,
"info": "Event Header Bank",
"entries": [
        {"name":"category",
                               "type": "L", "info": "Undefined"},
        {"name":"topology",
                               "type": "L", "info": "Undefined"},
        {"name":"beamCharge", "type":"F", "info":"Beam charge, gated (nano
        {"name":"liveTime",
                               "type": "D", "info": "Lifetime"},
                               "type": "F", "info": "Event Start Time (ns)"},
        {"name":"startTime",
        {"name":"RFTime",
                               "type": "F", "info": "RF Time (ns)"},
        {"name": "helicity",
                               "type": "B", "info": "Helicity of Event (+/-1,
        {"name":"helicityRaw", "type":"B", "info":"Helicity of Event (+/-1,
        {"name":"procTime",
                               "type": "F", "info": "Event Processing Time (U
```

Recommend: Use beamCharge from clasQADB

not REC::Event::beamCharge

see clas12root::qadb



### **Bank List**

```
Event
```

•RUN::config

• REC::Event

#### Physics

• REC::Particle

• REC::Response

• REC::Calorimeter

• REC::Scintillator

• REC:: Cherenkov

• REC::Track

REC::Forward Tagger

• REC::Traj

• REC::CovMat

#### Special

• HEL::online

HEL::flip (tag=1)

RUN::scaler (tag=1)

• RAW::scaler (tag=1)

RAW::epics (tag=1)

```
"name": "REC::Particle",
"group": 300,
"item" : 31,
"info": "Reconstructed Particle Information",
"entries": [
                         "type":"I", "info":"particle id in LUND conventions"},
    {"name":"pid",
    {"name":"px",
                         "type": "F", "info": "x component of the momentum (GeV)"},
    {"name":"py",
                         "type": "F", "info": "y component of the momentum (GeV)"},
                         "type": "F", "info": "z component of the momentum (GeV)"},
    {"name":"pz",
                         "type": "F", "info": "x component of the vertex (cm)"},
    {"name":"vx",
    {"name":"vy",
                         "type": "F", "info": "y component of the vertex (cm)"},
    {"name":"vz",
                         "type": "F", "info": "z component of the vertex (cm)"},
    {"name":"vt",
                         "type": "F", "info": "RF and z corrected vertex time (ns)"}
                         "type": "B", "info": "particle charge"},
    {"name": "charge",
    {"name":"beta",
                         "type": "F", "info": "particle beta measured by TOF"},
    {"name":"chi2pid",
                        "type":"F", "info":"Chi2 of assigned PID"},
    {"name":"status",
                         "type": "S", "info": "particle status (represents detector
```

Simplest analysis just needs REC::Particle 1 entry per reconstructed particle



https://clasweb.jlab.org/wiki/index.php/CLAS12\_DSTs

### **Bank List**

```
Event
```

• RUN::config

• REC::Event

#### Physics

• REC::Particle

• REC:: Response

• REC::Calorimeter

• REC::Scintillator

• REC:: Cherenkov

• REC::Track

REC::Forward Tagger

• REC::Traj

• REC::CovMat

#### Special

• HEL::online

• HEL::flip (tag=1)

RUN::scaler (tag=1)

RAW::scaler(tag=1)

RAW::epics (tag=1)

```
"name": "REC::Scintillator",
"group": 300,
"item" : 35,
"info": "Scintillator Responses for Particles bank",
"entries": [
    {"name":"index",
                        "type":"S", "info":"index of the hit in the specific detector bank"},
    {"name":"pindex",
                         "type":"S", "info":"row number in the particle bank hit is associated
    {"name":"detector",
                         "type":"B", "info":"Detector ID, as defined in org.jlab.detector.base
    {"name": "sector",
                         "type": "B", "info": "Sector of the Detector hit" },
    {"name":"layer",
                         "type":"B", "info":"Layer ID, as defined in org.jlab.detector.base.De
    {"name":"component", "type": "S", "info": "Component of the Detector hit"},
                         "type": "F", "info": "Energy associated with the hit (MeV)"},
    {"name": "energy",
                        "type": "F", "info": "Time associated with the hit (ns)"},
    {"name":"time",
    {"name": "path",
                         "type":"F", "info":"Path from vertex to the hit position (cm)"},
    {"name":"chi2",
                         "type":"F", "info":"Chi2 (or quality) of hit-track matching"},
    {"name":"x",
                         "type": "F", "info": "X coordinate of the hit (cm)"},
                        "type": "F", "info": "Y coordinate of the hit (cm)"},
    {"name":"y",
    {"name":"z",
                         "type": "F", "info": "Z coordinate of the hit (cm)"},
    {"name":"hx",
                         "type": "F", "info": "X coordinate of the matched hit (cm)"},
    {"name":"hy",
                         "type": "F", "info": "Y coordinate of the mathced hit (cm)"},
    {"name": "hz",
                         "type": "F", "info": "Z coordinate of the matched hit (cm)"},
    {"name":"status",
                        "type": "S", "info": "hit status"},
```

1 entry per scintillator hit associated with a particle.

The *i*th scintillator entry does not generally correspond to the *i*th REC::particle

Entry. Must use **pindex** 

https://clasweb.jlab.org/wiki/index.php/CLAS12\_DSTs

# Fast Histogramming

```
//particleDraw /dir/file.hipo Ex2 HipoDraw.C
                                              With this condition
                  Draw this
 hists.Hist1D("P.Theta*TMath::RadToDeg()",180,0,180,"PBANK.Px");
 hists.Hist1D("P.Phi*TMath::RadToDeg()",180,-180,180,"PBANK.Px");
 hists.Hist1D("P.P",100,0.1,12,"PBANK.Px");
 hists.Hist1D("P.Time-EVNT.StartTime",1000,-200,200,"P.Time&&PBANK.Px"); //Note zero suppression
 hists.Hist1D("atan2(sqrt(PBANK.Px*PBANK.Px+PBANK.Py*PBANK.Py),PBANK.Pz)*57.295780",180,0,180,"P.Time&&PBANK.Px");
 hists.Hist1D("atan2(PBANK.Py,PBANK.Px)*TMath::RadToDeg()",180,-180,180,"P.Time&&PBANK.Px");
 hists.Hist1D("sqrt(PBANK.Px*PBANK.Px+PBANK.Py*PBANK.Py+PBANK.Pz*PBANK.Pz)",100,0.1,12);
 hists.Hist1D("FTOF1B.Time-EVNT.StartTime",1000,-200,200,"P.Time&&PBANK.Px&&PBANK.Px");
 hists.Hist1D("P.Theta*TMath::RadToDeg()",180,0,180,"P.Pid==11&&PBANK.Px");
 hists.Hist1D("P.Phi*TMath::RadToDeq()",180,-180,180,"P.Pid==11&&PBANK.Px");
 hists.Hist1D("P.P",100,0.1,12,"P.Pid==11");
 hists.Hist1D("P.Time-EVNT.StartTime".1000.-200.200."P.Time&&P.Pid==11&&PBANK.Px"):
 hists.Hist1D("P.Theta*TMath::RadToDeg()",180,0,180,"P.Pid==2212&&PBANK.Px");
                                                                                     Fill all simultaneously
 hists.Hist1D("P.Phi*TMath::RadToDeg()",180,-180,180,"P.Pid==2212&&PBANK.Px");
                                                                                     And plot on 4x3 canvas
 hists.Hist1D("P.P",100,0.1,12,"P.Pid==2212&&PBANK.Px");
 hists.Hist1D("P.Time-EVNT.StartTime",1000,-200,200,"P.Time&&P.Pid==2212&&PBANK.Px")->Draw("(4x3)");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,-180,180,-180,"P.Pid==11");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,180,-180,180,"P.Pid==-11");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,-180,180,"P.Pid==22");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,-180,180,-180,180,"P.Pid==2212");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,180,-180,180,"P.Pid==211");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,-180,180,-180,180,"P.Pid==-211");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,180,-180,180,"P.Pid==321");
 hists.Hist2D("P.Theta*TMath::RadToDeg():P.Phi*TMath::RadToDeg()",180,0,180,-180,180,"P.Pid==-321")->Draw("(4x2)col1");
 hists.Hist2D("P.P:P.Beta",100,0,10,100,0,2,"P.Beta");
 hists.Hist2D("P.P:P.Beta",100,0,10,100,0,2,"P.Beta&&P.Region==FT");
```

### Create small ROOT trees

```
//particleTree /dir/file.hipo out.root Ex4 TreeMaker.C
 //treemaker.SetEntries(1E5);//only process given number of events
 //add event header branch, includes start time
 //treemaker.UseEventData();
 //make branch with given formula and alias it to name Time
 //give branch type with /F = float etc.
 treemaker.Branch("P.Time-PBANK.Vt/F","ToF");
 treemaker.Branch("P.Time-PBANK.FTBVt/F","FTBToF");
 treemaker.Branch("P.Time/F");
 treemaker.Branch("P.Path/F");
 treemaker.Branch("P.DetEnergy/P.P/F", "SampFrac");
 treemaker.Branch("HTCC.Nphe/F");
 treemaker.Branch("PBANK.Px/F");
 treemaker.Branch("PBANK.Py/F");
 treemaker.Branch("PBANK.Pz/F");
 treemaker.Branch("PBANK.Vx/F");
 treemaker.Branch("PBANK.Vy/F");
 treemaker.Branch("PBANK.Vz/F");
 treemaker.Branch("PBANK.Pid/I");
 treemaker.Branch("PBANK.FTBPid/I");//FT based PID
 //e.g. Only save electron information
 //treemaker.AddParticleCut("PBANK.Pid==11");
 //Event topology cuts
 //treemaker.AddAtLeastPid(211,1); //at least 1 pi+
 // treemaker.AddExactPid(11,1); //exactly 1 electron
 // treemaker.AddZeroOfRestPid(); //nothing else, if not this line any of anything else
 treemaker.Fill();
```



# clas12root access to particle data

```
Clas12reader::getDetParticles → C++ vector of region_particles
region_particle points to REC::Particle and REC::Response data
Responses are already linked using pindex
Define a specific region_particle class for FT, FD and CD regions
This allows us to define which detectors may have been hit
and define getTime() etc. differently for each
   i.e. use FTOF1B or CTOF
Usage : p->bank()->getItem();
Where bank = pbank, sci, cal, che, ... i.e
                                                 pbank=REC::Particle
REC::Response
       Item = Px, Vz, Pid, Time, Sector,...
       p->pbank()->getPid();
                                       Use specific detector names
       p->sci(FTOF2)->getEnergy();
                                       FTOF1A, PCAL,...to get its response.
                                       Will be 0 if no hit.
       p->trk(DC)->getSector();
       p->che(HTCC)->getNphe();
https://github.com/JeffersonLab/clas12root/blob/master/AccesssingBankDataInCpp.txt
```

# Clas12root particle C++ std::vectors

```
for(auto& p : c12.getDetParticles()) //range based for loop
   if(p->qetPid()==11){
      electron.SetXYZM(p->pbank()->getPx(),p->pbank()->getPy(),
                       p->pbank()->getPz,0.0051);
      Double_t eToF = p->getTime()- p->pbank()->getVt();
OR (probably more useful, if using EB Pid)
auto electrons = c12.getByID(11); //filter DetParticles
if(electrons.empty()==false){
   auto& p = electrons[0];
   electron.SetXYZM(p->pbank()->getPx(),p->pbank()->getPy(),
                    p->pbank()->getPz, 0.0051);
   Double_t eToF = p->getTime()- p->pbank()->getVt();
```

Note, what getTime returns depends on which detector region the particle was reconstructed in. e.g. if FD then FTOF1B or FTOF1A or FTOF2 or PCAL

# Clas12root event information

```
clas12reader c12("file.hipo");
   REC::Event
      c12.event()->getStartTime()
      c12.event()->getHelicity()
   RUN::config
      c12.runconfig()->getTrigger()
      c12.runconfig()->getRun()
   MC::Lund
      c12.mcparts()->getPx(i)
      c12.mcparts()->getPid(i)
   0r
      c12.mcparts()->setEntry(i);
      c12.mcparts()->getPx();
      c12.mcparts()->getPid();
alternatively for trigger can use
         c12.checkTriggerBit(ibit);
```



# Clas12root event loops Loop over files

```
clas12root::HipoChain chain;
chain.Add("/where/clas12data/dst1.hipo");
chain.Add("/where/clas12data/dst2.hipo");
chain.SetReaderTags({0}); //create clas12reader with just tag 0 events
//configure reader
 auto config c12=chain.GetC12Reader();
config c12->addExactPid(2212,1); //exactly 1 proton
config c12->AddAtLeastPid(211,1); //at least 1 pi+
//config_c12->useFTBased(); //and use the Pids from RECFT
//get loop reader, need auto& ...
 auto& c12=chain.C12ref();
TLorentzVector p4p:
TLorentzVector p4pim;
TLorentzVector p4L;
//loop over all events in chain of files
while (chain.Next()){
    auto protons=c12->getByID(2212);
    auto pims=c12->getByID(-211);
   p4p.SetXYZM(protons[0]->pbank()->getPx(),protons[0]->pbank()->getPy(),
                protons[0]->pbank()->getPz(),Mproton);
   p4pim.SetXYZM(pims[0]->pbank()->getPx(),pims[0]->pbank()->getPy(),
                  pims[0]->pbank()->getPz(),Mpi);
   p4L=p4p+p4pim:
```



### clas12reader

# **Prepare Databases**

```
clas12root PrepareDatabases.C
/* For rcdb creaate a HipoChain of data files and the RCDB info will be
   downloaded and saved in a ROOT file for those runs*/
clas12databases::SetRCDBRemoteConnection();
                                                         You need to edit
clas12root::HipoChain chain;
                                                         Your chain files!!!
//Add you data files here
chain.Add("/work/jlab/clas12data/skim14_*.hipo");
chain.WriteRcdbData("rcdb.root");
→ create local root file copy of rcdb for files in your chain
(because rcdb sqlite would not open sqlite file in C++...)
/* For ccdb just download the most recent snapshot to read with sqlite
gSystem->Exec("wget https://clasweb.jlab.org/clas12offline/sqlite/ccdb/latest.sqlite");
gSystem->Exec("mv latest.sqlite ccdb.sqlite");
```

Note run # 10 and 11 reserved for simulated data files Should there be anymore ?



# HipoChain

### rcdb access

```
clas12databases::SetCCDBLocalConnection("ccdb.sqlite"); //if using ccdb
clas12databases::SetRCDBRootConnection("rcdb.root");//if using rcdb
clas12root::HipoChain chain;
chain.Add("/work/jlab/clas12data/skim14_005038.hipo");
chain.Add("/work/jlab/clas12data/skim14 005039.hipo");
chain.SetReaderTags({0}); //create clas12reader with just tag 0 events
auto config c12=chain.GetC12Reader();
/*Get some data from the
  rcdb info,(&=> reference, will update for next file)
  see Clas12Banks/rcdb vals for full list of data
  this should match https://clasweb.jlab.org/rcdb/conditions*/
auto& rcdbData= config c12->rcdb()->current();//struct with all relevent rcdb values
//now get reference to (unique)ptr for accessing data in loop
//this will point to the correct place when file changes
auto& c12=chain.C12ref();
while (chain.Next()){
  //The following run conditions can be returned directly by c12
  cout<<"Event count: "<<rcdbData.event_count<<endl;</pre>
  cout<<"Beam energy: "<<rcdbData.beam_energy<<endl;</pre>
  cout<<"Beam current: "<<rcdbData.beam current<<endl;</pre>
```

### clas12reader

### ccdb access

```
clas12databases::SetCCDBLocalConnection("ccdb.sqlite"); //if using ccdb
 clas12databases::SetRCDBRootConnection("rcdb.root");//if using rcdb
 clas12root::HipoChain chain;
 chain.Add("/work/jlab/clas12data/skim14_005038.hipo");
 chain.Add("/work/jlab/clas12data/skim14 005039.hipo");
 chain.SetReaderTags({0}); //create clas12reader with just tag 0 events
 auto config c12=chain.GetC12Reader();
/*make a request for ccdb information (&=> reference, will update for next file)
 for list of tables , https://clasweb.jlab.org/cgi-bin/ccdb/objects*/
auto& ccdbElSF=config c12->ccdb()->requestTableDoubles("/calibration/eb/electron sf");
                 Returns a vector<vector<double>>;
 auto& c12=chain.C12ref();
while (chain.Next()){
   if(c12->ccdb()){
                                                       Table values will update
     cout<< ccdbElSF.size()<<endl;</pre>
     cout<< ccdbElSF[0].size()<<endl;</pre>
                                                      When file changes
     cout<< ccdbElSF[0][5]<<endl;</pre>
     cout<< ccdbElSF[1][5]<<endl;</pre>
```

### clas12reader

# qcdb

```
clas12databases::SetCCDBLocalConnection("ccdb.sqlite"); //if using ccdb
clas12databases::SetRCDBRootConnection("rcdb.root");//if using rcdb
clas12root::HipoChain chain;
chain.Add("/work/jlab/clas12data/skim14 005038.hipo");
chain.Add("/work/jlab/clas12data/skim14 005039.hipo");
chain.SetReaderTags({0}); //create clas12reader with just tag 0 events
auto config c12=chain.GetC12Reader();
if(config c12->qadb()!=nullptr){
  config c12->db()->qadb requireOkForAsymmetry(true);
  config_c12->db()->qadb requireGolden(true);
                                                                  Configure gadb requirements
  config c12->db()->qadb addQARequirement("MarginalOutlier");
  config c12->db()->gadb addOARequirement("TotalOutlier");
    clas12reader will only process events that pass quality assurance
    * and ignore those which fail
  config_c12->applyQA();
//now get reference to (unique)ptr for accessing data in loop
//this will point to the correct place when file changes
                                                                     Only events passing ga
auto& c12=chain.C12ref();
while (chain.Next()){
                                                                     processed
* The clasqaDB software also provides the accumulated charge for events
* that pass the quality assurance requirements.
cout<<"Accumulated charge past QA: "<< chain.TotalBeamCharge()<<" nC"<<endl;</pre>
```

Total charge for files that pass your qadb conditions

# Clas12reader Additional banks

```
clas12reader c12{"file.hipo"};
//get track based hits id and layers
//Add extra bank for reading and get its ID
auto idx TRCKHits= c12.addBank("TimeBasedTrkq::TBHits");
//Add an item in the bank for reading and get its ID
auto iTrckId = c12.getBankOrder(idx TRCKHits,"id");
auto iTrckLayer = c12.getBankOrder(idx TRCKHits, "layer");
while(c12.next()==true){
auto Nhits=c12.getBank(idx TRCKHits)->getRows();
//loop over time based tracks for this event
for(auto itr=0;itr<Nhits;itr++){</pre>
   auto id=c12.getBank(idx TRCKHits)->getInt(iTrckId,itr);
   auto layer=c12.getBank(idx_TRCKHits)->getInt(iTrckLayer,itr);
```

### clas12writer

### Tool to produce small files with selected events and banks

```
//initialising clas12writer with path to output file
clas12writer c12writer("out.hipo");
//can as writer not to write certain banks
c12writer.skipBank("REC::CovMat");
//create the event reader
clas12reader c12("in.hipo");
//assign a reader to the writer
c12writer.assignReader(c12);
c12->addExactPid(11,1); //add filters, exactly 1 electrons
while(c12.next()==true){
  // get particles by type
  auto electrons=c12.getByID(11);
  auto protons=c12.getByID(2212);
  auto pips=c12.getByID(211);
  auto pims=c12.getByID(-211);
  if(electrons.size()>0 &&pips.size()>0 &&pims.size()>0&&protons.size()>0){
       // set the particle momentum
    SetLorentzVector(el,electrons[0]);
    SetLorentzVector(pr,protons[0]);
    SetLorentzVector(pip,pips[0]);
    SetLorentzVector(pim.pims[0]);
    //calculate mssing vector for exclusivity
    TLorentzVector miss=beam+target-el-pr-pip-pim;
    if(TMath::Abs(miss.M2())<2){</pre>
      //Write event
      c12writer.writeEvent();
```



### clas12reader

### Simulated data

```
while (chain.Next()){
  auto mceve=c12->mcevent():
                                                                                  Use mcevent()
 cout<<" beam energy "<<mceve->qetEbeam()<<" type "<<mceve->qetBtype()<<endl;</pre>
                                                                                  And mcparts()
  auto mcpbank=c12->mcparts();
 const Int t Ngen=mcpbank->getRows();
  for(Int t i=0;i<Ngen;i++){</pre>
                                    Loop over particles as
   mcpbank->setEntry(i);
                                    ordered in Lund file
   auto px=mcpbank->getPx();
                                    (not as ordered in REC::Particle!)
   auto py=mcpbank->getPy();
   auto pz=mcpbank->getPz();
   auto pm=mcpbank->getMass();
   p4.SetXYZM(px,py,pz,pm);
   auto pid = mcpbank->getPid();
   cout<<" particle "<<i<<" "<<pid<< " p4 = "<<p4.X()<<","
       <<p4.Y()<<","<<p4.Z()<<","<<p4.T()<<" and mass "<<p4.M()<<endl;
For when truth matching included in simulated DSTs
    while (chain.Next()){
      //loop over all reconstructed particles
      for(auto p : c12->getDetParticles()){
        if(p->mc()->isMatched()){//this particle has an mc match
          //if charged FD, check for sufficient layers
          if( p->getRegion()==clas12::FD && p->par()->getCharge() )
            if(p->mc()->qetMatch()->checkFDSuperLayers(5,4)==false)
              continue:
          // p->mc()->qetMatch()->checkBitInPattern(33);//check other bits
          hPDiff->Fill(p->getMCPDiff());
          hThDiff->Fill(p->qetMCThetaDiff()*TMath::RadToDeq());
          hPhDiff->Fill(p->getMCPhiDiff()*TMath::RadToDeg());
```



### clas12reader

## Summary

Clas12root provides access to all data required for analysing Clas12 reactions

All particle and detector information from HiPO DSTs MC truth information from MC::Lund banks All database information from rc,cc and qa Dbs

It can be run in ROOT scripts, included in compiled C++ code Or used in Jupyter notebooks via pyROOT.

Fast drawing and skimming routines available (see docs)

DST filtering from clas12writer

